

THE VADLE®-CURB BOX LOCK

NOTE: CURB STOPS AND CURB BOXES INSTALLATION INSTRUCTIONS:

- 1) WHEN INSTALLING NEW CURB STOPS, VERIFY THAT THE SURFACE IS PROPERLY FINISHED AND LEVEL UNDER THE CURB STOP.
- 2) IF THE NEW STOP WILL NOT FIT OVER THE EXISTING CURB STOP, THEN PART OF THE EXISTING STOP MUST BE REMOVED TO ALLOW THE NEW STOP TO FIT OVER THE EXISTING CURB STOP. THE NEW STOP MUST BE INSTALLED WITH THE CORRECT TYPED AND SIZED CURB STOP.
- 3) THE NEW CURB STOP MUST BE INSTALLED WITH THE CORRECT TYPED AND SIZED CURB STOP.
- 4) THE NEW CURB STOP MUST BE INSTALLED WITH THE CORRECT TYPED AND SIZED CURB STOP.
- 5) THE NEW CURB STOP MUST BE INSTALLED WITH THE CORRECT TYPED AND SIZED CURB STOP.

ALL CURB BOXES WITH THE VADLE® PLACED UPRIGHT DOWN

- 1) WHEN INSTALLING A 7" HIGH VADLE® CURB STOP ON A 7" HIGH EXISTING CURB STOP, VERIFY THAT THE VADLE®-UPRIGHT CURB STOP FITS OVER THE EXISTING CURB STOP UNDER THE CURB STOP.
- 2) TO SET THE VADLE® ON THE EXISTING CURB STOP, PUT THE CURB STOP OVER THE VADLE®.
- 3) PLACE THE CURB STOP TO SECURELY IN THE CURB BOX. THE VADLE®-CURB STOP IS A SINGLE LINE AND FOUNDATION IS NOT APPLICABLE.

SOFT OR UNSTABLE GROUND:

- 1) WHEN INSTALLING ON UNSTABLE GROUND, VERIFY THAT THE VADLE®-CURB STOP IS SECURED TO A SUFFICIENTLY FIRM SURFACE AS A BASIS OF A SUPPORTING FOUNDATION.
- 2) VERIFY THAT THE VADLE®-CURB STOP IS SECURED TO A SUFFICIENTLY FIRM SURFACE AS A BASIS OF A SUPPORTING FOUNDATION.

